



## USER MANUAL LQT40A



**TILLQUIST GROUP AB**

Box 1120  
SE-164 22 Kista  
Sweden  
Tel: +46 8 594 632 00  
[info@tillquist.com](mailto:info@tillquist.com)  
[www.tillquist.com](http://www.tillquist.com)

*The LQT40A is a programmable multi transducer for power systems. All electrical quantities for AC current and voltage (True RMS) are covered by one single unit. It can measure single phase systems up to 4-wire unbalanced load systems. With its 4 analog and 2 digital outputs together with a serial interface RS 485, Modbus, LQT40A offers almost unlimited possibilities.*

*Our free transducer configuration software "ConfigLQT" is used to easily program the LQT40A via its USB-port.*

## Table of contents

1	Instructions .....	1
1.1	Purpose of this document .....	1
1.2	Mounting .....	1
1.3	Installation .....	1
1.4	Operation .....	1
1.5	Safety.....	1
1.6	Warning!.....	2
1.7	Maintenance .....	2
1.8	Symbols .....	2
2	Connections .....	3
2.1	Connection diagram.....	3
2.2	Electric connection .....	4
2.3	Connection diagrams – System connection.....	4
3	Measuring .....	7
3.1	Measured quantities .....	7
3.2	Measuring system .....	8
3.2.1	Phase-Locked loop - PLL .....	8
3.2.2	Soft mode.....	8
3.2.3	Block diagram.....	8
3.2.4	Frequency filter.....	8
4	Outputs .....	9
4.1	Analog output .....	9
4.2	Digital outputs .....	9
4.3	Modbus RS485 .....	9
4.3.1	Interface Modbus RTU .....	9
4.3.2	Modbus mapping .....	10
5	Commissioning.....	12
5.1	Programming of the transducer .....	12
5.2	LED functionality .....	12
6	Technical Data.....	13

# 1 Instructions

## 1.1 Purpose of this document

This document describes how to use the LQT40A multi transducer. The user manual is intended to be used by:

- installation personnel and commissioning engineers
- service and maintenance personnel
- planners

## 1.2 Mounting

The transducer can be mounted on a 35 mm DIN rail according EN50022, on a wall or device cabinet for suitable protection. The enclosure shall not be accessible without tools.

## 1.3 Installation

The installation shall be made by trained personnel and in accordance with applicable regulations. Before the installation, please check that the transducer is the correct type and complies with the installation needs.

	A marked external circuit breaker to turn off the power supply to the transducer must be installed near. The OFF-position shall be clearly marked.
	Attention: Danger to life! Ensure that all leads are free of potential when connection them!
	Voltage measurements inputs must have circuit breakers or fuses rated 5 Amps or less.
	The measuring circuits from the current transformers must be short-circuited before disconnection. No fuses are allowed on the current inputs.

## 1.4 Operation

The transducer is intended for operation at an altitude not exceeding 2000 m and in an environment that is not considered as wet location.

Operation temperature: -20...22...24...+55°C

Proper function is only guaranteed if the USB is not connected to the transducer and all the instructions in this manual are followed for safety reasons.

## 1.5 Safety

All inputs and outputs are galvanically isolated from each other.

Protection class:	II, protective insulation, voltage inputs via protective impedance.
Protection:	IP40 (housing), IP20 (terminals)

## 1.6 Warning!

Connection must comply with current regulations for systems with rated voltage up to 1000 V. Before switching on or off and if the housing is removed, all voltages to the equipment must be switched off and external currents circuit shorted before disconnected.

## 1.7 Maintenance

The transducer requires no maintenance. Any repairs shall be performed by trained personnel, or the equipment shall be returned to the supplier for repair.

## 1.8 Symbols



Double insulated device, protection class 2.



Warning for life-threatening or hazardous for properties situations.



Caution, possibility of electric shock



Read the manual before use



The device must be discarded in a professional way




CE conformity mark

## 2 Connections

### 2.1 Connection diagram

Voltage input		
$U_{L1}$	2	
$U_{L2}$	5	
$U_{L3}$	8	
N	11	
Current input	In	Out
$I_{L1}$	1	3
$I_{L2}$	4	6
$I_{L3}$	7	9
Aux Power Supply		
	13	
	14	
Analog Output		
A1	20 +	
	21 -	
A2	22 +	
	23 -	
A3	24 +	
	25 -	
A4	26 +	
	27 -	
Digital Output		
D1	30, 31	
D2	32, 33	
Modbus RS485		
A	40	
B	41	
GND	42	



## 2.2 Electric connection


The plug-in terminals needs to be removed before accessing the input terminals.

<b>Inputs L1, L2, L3, N, I1, I2, I3, Aux.supply</b>	
Wire section:	6.0 mm <sup>2</sup> / 10 AWG
Clamp opening size:	3.2 × 3.9 mm
Wire stripping:	max 9 mm
Recommended torque:	0.8 - 0.88 Nm / 7.2 - 7.9 in.lbs
<b>Analog Outputs, Digital Outputs, RS 485 (plug-in terminals)</b>	
Wire section:	2.5 mm <sup>2</sup> / 14 AWG
Clamp opening size:	2.8 × 3.1 mm
Wire stripping:	max 8 mm
Recommended torque:	0.5 - 0.55 Nm / 4.5 - 4.9 in.lbs

## 2.3 Connection diagrams – System connection

LQT40A system connection is programmable from single phase to 4-wire balanced or unbalanced connection.




<b>Configurable System Connection</b>												
<b>System connection</b>	<b>Application</b>	I1	I2	I3	U1	U2	U3	N	U12	U23	U31	
-00	4wire, 3 phase symmetric load	X	-	-	X	-	-	X	-	-	-	
-01	1-wire, 1 phase	X	-	-	X	-	-	X	-	-	-	
-02	3-wire, 3 phase symmetric load	X	-	-	-	-	-	-	X	-	-	
-03	3-wire, 3 phase symmetric load	X	-	-	-	-	-	-	-	X	-	
-04	3-wire, 3 phase symmetric load	X	-	-	-	-	-	-	-	-	X	
-05	3-wire, 3 phase symmetric load	X	-	-	X	X	X	-	X	X	X	
-09	3-wire, 3 phase asymmetric load	X	-	X	X	X	X	-	X	X	X	
-11	4-wire, 3 phase asymmetric load	X	X	X	X	X	X	X	X	X	X	
-11	4-wire, 3 phase asymmetric load Open Delta	X	X	X	X	X	X	-	X	X	X	



-05

3-phase  
1 element




3-wire  
3-phase symmetrical load



-09

3-phase  
2 elements




3-wire  
3-phase asymmetrical load



-11

3-phase  
3 elements

4-wire  
3-phase asymmetrical load



### 3 Measuring

#### 3.1 Measured quantities

Prefix	Quantity	Calculation	System / Phase
I	Input current	$(I_1+I_2+I_3)/3$	System
I <sub>1</sub>	Phase current L1		L1
I <sub>2</sub>	Phase current L2		L2
I <sub>3</sub>	Phase current L3		L3
U	Input voltage	$(U_1+U_2+U_3)/3$	System
U <sub>1</sub>	L1 Phase voltage		L1
U <sub>2</sub>	L2 Phase voltage		L2
U <sub>3</sub>	L3 Phase voltage		L3
P	Active power	$P_1+P_2+P_3$	System
P <sub>1</sub>	Active power L1		L1
P <sub>2</sub>	Active power L2		L2
P <sub>3</sub>	Active power L3		L3
Q	Reactive power	$Q_1+Q_2+Q_3$	System
Q <sub>1</sub>	Reactive power L1		L1
Q <sub>2</sub>	Reactive power L2		L2
Q <sub>3</sub>	Reactive power L3		L3
S	Apparent power	$S_1+S_2+S_3$	System
S <sub>1</sub>	Apparent power L1		L1
S <sub>2</sub>	Apparent power L2		L2
S <sub>3</sub>	Apparent power L3		L3
U <sub>12</sub>	Main voltage L1-L2		L1 - L2
U <sub>23</sub>	Main voltage L2-L3		L2 - L3
U <sub>31</sub>	Main voltage L3-L1		L3 - L1
PF	Active power factor	P/S	System
PF <sub>1</sub>	Active power factor	$\text{COS}(\varphi_1)=P_1/S_1$	L1
PF <sub>2</sub>	Active power factor	$\text{COS}(\varphi_2)=P_2/S_2$	L2
PF <sub>3</sub>	Active power factor	$\text{COS}(\varphi_3)=P_3/S_3$	L3
QF	Reactive power factor	Q/S	System
QF <sub>1</sub>	Reactive power factor	$\text{SIN}(\varphi_1)=Q_1/S_1$	L1
QF <sub>2</sub>	Reactive power factor	$\text{SIN}(\varphi_2)=Q_2/S_2$	L2
QF <sub>3</sub>	Reactive power factor	$\text{SIN}(\varphi_3)=Q_3/S_3$	L3
LF	LF factor	$\text{sign}(Q)*(1- PF )$	System
LF <sub>1</sub>	LF factor	$\text{sign}(Q_1)*(1- PF_1 )$	L1
LF <sub>2</sub>	LF factor	$\text{sign}(Q_2)*(1- PF_2 )$	L2
LF <sub>3</sub>	LF factor	$\text{sign}(Q_3)*(1- PF_3 )$	L3
PA	Phase angel	$PA=(PA_1+PA_2+PA_3)/3$	System
PA <sub>1</sub>	Phase angel	$\varphi_1=\text{ARCCOS}(P_1/S_1)/\pi*180*\text{sign}(P_1)$	L1
PA <sub>2</sub>	Phase angel	$\varphi_2=\text{ARCCOS}(P_2/S_2)/\pi*180*\text{sign}(P_2)$	L2
PA <sub>3</sub>	Phase angel	$\varphi_3=\text{ARCCOS}(P_3/S_3)/\pi*180*\text{sign}(P_3)$	L3
IS	Input current with sign	$(IS_1+IS_2+IS_3)/3$	System
IS <sub>1</sub>	Phase current with sign	$I_1*\text{sign}(P_1)$	L1
IS <sub>2</sub>	Phase current with sign	$I_2*\text{sign}(P_2)$	L2
IS <sub>3</sub>	Phase current with sign	$I_3*\text{sign}(P_3)$	L3
P_I <sub>1</sub> _U <sub>12</sub>	Active power, System connection -02		System
P_I <sub>1</sub> _U <sub>23</sub>	Active power, System connection -03		System
P_I <sub>1</sub> _U <sub>31</sub>	Active power, System connection -04		System
Q_I <sub>1</sub> _U <sub>12</sub>	Reactive power, System connection -02		System
Q_I <sub>1</sub> _U <sub>23</sub>	Active power, System connection -03		System
Q_I <sub>1</sub> _U <sub>31</sub>	Active power, System connection -04		System
F	Frequency		System

## 3.2 Measuring system

### 3.2.1 Phase-Locked loop - PLL


The measuring system use a phase-locked loop (PLL) between 10-120 Hz. All quantities are being measured. The number of samples per period is deppending of the frequency.

### 3.2.2 Soft mode

A fixed sample rate of 1800 samples/second (soft mode) is used when the frequency is lower than 10 Hz or higher than 120 Hz. Measured quantities in soft mode are voltage (U), current (I) and frequency (F).

### 3.2.3 Block diagram

Schematic block diagram of measure process.



\* Soft mode = 1800 samples / second

### 3.2.4 Frequency filter


The frequency measurement is low-pass filtered with a binomial filter. This setting determines the length of the filter in periods of the measured frequency. A shorter length gives a more responsive measurement. A longer length gives a slower, more stable measurement.

Frequency filter is adjustable between 0 – 10.

## 4 Outputs

### 4.1 Analog output

The analog outputs can be assigned any measured quantity, see table "3.1 Measured quantities". The output is available with three different ranges,  $\pm 20$  mA,  $\pm 5$  mA or  $\pm 10$  V. The resolution of the output is 16 bits. 2 to 5 characteristic point can be programmed for each channel. It is possible to set a fixed value for the output. Fixed output is useful when testing an installation. Off position is the same as 0 mA or V.



### 4.2 Digital outputs

Digital output is used to pulse energy, P (active power) or Q (reactive power) as export or import.

This panel configures a binary output for Pulse mode. It includes settings for Energy (P or Q), Direction (Exported), Pulse frequency (500 imp/kWh Secondary, 1732.1 imp/h), Pulse value (0.025 imp/Wh Primary, 40 Wh/imp Primary), and Pulse length (50 ms).

## 4.3 Modbus RS485

### 4.3.1 Interface Modbus RTU

Protocol: Modbus RTU

Physics: RS-485, max 1200 m (4000 ft)

Baud rate: 2400, 4800, 9600, 19200, 38400 Baud

Number of participants: max 32

For additional information about Modbus: [www.modbus.org](http://www.modbus.org)

### 4.3.2 Modbus mapping

Different Modbus protocol profiles are available, depending of needs and the update frequency of data.

#### Modbus protocol profile Mapping 001

The output registry for the measured quantities is updated every 100 ms with profile mapping 001.

adr	format	parameter		explanation	
0	binary32	F	Hz	Frequency	system
2	binary32	I	A	Input current	system $I = (I1+I2+I3)/3$
4	binary32	I1	A	Phase current	L1
6	binary32	I2	A	Phase current	L2
8	binary32	I3	A	Phase current	L3
10	binary32	U	V	Input voltage	system $U = (U1+U2+U3)/3$
12	binary32	U1	V	Phase voltage	L1-N
14	binary32	U2	V	Phase voltage	L2-N
16	binary32	U3	V	Phase voltage	L3-N
18	binary32	U12	V	Main voltage	L1-L2
20	binary32	U23	V	Main voltage	L2-L3
22	binary32	U31	V	Main voltage	L3-L1
24	binary32	P	W	Active power	system $P = P1+P2+P3$
26	binary32	P1	W	Active power	L1
28	binary32	P2	W	Active power	L2
30	binary32	P3	W	Active power	L3
32	binary32	Q	var	Reactive power	system $Q = Q1+Q2+Q3$
34	binary32	Q1	var	Reactive power	L1
36	binary32	Q2	var	Reactive power	L2
38	binary32	Q3	var	Reactive power	L3
40	binary32	S	VA	Apparent power	system $S = S1+S2+S3$
42	binary32	S1	VA	Apparent power	L1 $S1 = U1*I1$
44	binary32	S2	VA	Apparent power	L2 $S1 = U1*I2$
46	binary32	S3	VA	Apparent power	L3 $S1 = U1*I3$
48	binary32	LF	-	LF factor	system $LF = \text{sign}(Q)*(1- PF )$
50	binary32	LF1	-	LF factor	L1 $LF1 = \text{sign}(Q1)*(1- PF1 )$
52	binary32	LF2	-	LF factor	L2 $LF2 = \text{sign}(Q2)*(1- PF2 )$
54	binary32	LF3	-	LF factor	L3 $LF3 = \text{sign}(Q3)*(1- PF3 )$
56	binary32	PF	-	Active power factor	system $PF1 = P/S = \text{COS}(\phi) = \text{COS}(PA)$
58	binary32	PF1	-	Active power factor	L1 $PF1 = P1/S1 = \text{COS}(\phi1) = \text{COS}(PA1)$
60	binary32	PF2	-	Active power factor	L2 $PF2 = P2/S2 = \text{COS}(\phi2) = \text{COS}(PA2)$
62	binary32	PF3	-	Active power factor	L3 $PF3 = P3/S3 = \text{COS}(\phi3) = \text{COS}(PA3)$
64	binary32	QF	-	Reactive power factor	system $QF1 = Q/S = \text{SIN}(\phi) = \text{SIN}(PA)$
66	binary32	QF1	-	Reactive power factor	L1 $QF1 = Q1/S1 = \text{SIN}(\phi1) = \text{SIN}(PA1)$
68	binary32	QF2	-	Reactive power factor	L2 $QF2 = Q2/S2 = \text{SIN}(\phi2) = \text{SIN}(PA2)$
70	binary32	QF3	-	Reactive power factor	L3 $QF3 = Q3/S3 = \text{SIN}(\phi3) = \text{SIN}(PA3)$
72	binary32	PA	°el	Phase angle $\phi$	system $PA = (PA1+PA2+PA3)/3$
74	binary32	PA1	°el	Phase angle $\phi_1$	L1 $PA1 = \text{ARCCOS}(P1/S1)/\pi*180*\text{sign}(P1)$
76	binary32	PA2	°el	Phase angle $\phi_2$	L2 $PA2 = \text{ARCCOS}(P2/S2)/\pi*180*\text{sign}(P2)$
78	binary32	PA3	°el	Phase angle $\phi_3$	L3 $PA3 = \text{ARCCOS}(P3/S3)/\pi*180*\text{sign}(P3)$
80	binary32	IS	A	Input current with sign	system $IS = (IS1+IS2+IS3)/3$
82	binary32	IS1	A	Phase current with sign	L1 $IS1 = I1*\text{sign}(P1)$
84	binary32	IS2	A	Phase current with sign	L2 $IS2 = I2*\text{sign}(P2)$
86	binary32	IS3	A	Phase current with sign	L3 $IS3 = I3*\text{sign}(P3)$
120	binary32	CTR	A/A	primary to secondary current transformer ratio (i.e. 600A/1A)	
122	binary32	PTR	V/V	primary to secondary potential (voltage) transformer ratio (i.e. 220kV/110V)	

## Modbus protocol profile Mapping 002

The output registry for the measured quantities is updated every 25 ms with profile mapping 002.

adr	format	parameter			explanation	
0	binary32	F	Hz	Frequency	system	
2	binary32	I	A	Input current	system	$I = (I1+I2+I3)/3$
4	binary32	I1	A	Phase current	L1	
6	binary32	I2	A	Phase current	L2	
8	binary32	I3	A	Phase current	L3	
10	binary32	U	V	Input voltage	system	$U = (U1+U2+U3)/3$
12	binary32	U1	V	Phase voltage	L1-N	
14	binary32	U2	V	Phase voltage	L2-N	
16	binary32	U3	V	Phase voltage	L3-N	
18	binary32	U12	V	Main voltage	L1-L2	
20	binary32	U23	V	Main voltage	L2-L3	
22	binary32	U31	V	Main voltage	L3-L1	
24	binary32	P	W	Active power	system	$P = P1+P2+P3$
26	binary32	Q	var	Reactive power	system	$Q = Q1+Q2+Q3$

## Modbus function code 04: Read Input Registers

The data format used is IEEE 754 single-precision binary floating-point format: binary32

Parameters are represented as two consecutive Modbus registers.

The value of a parameter is represented in SI unit as secondary values on transducer input.

To calculate primary values, use the primary to secondary transformer ratio of parameter CTR, PTR

The CTR and PTR parameter can be configured by the user by editing primary to secondary current- and voltage-ratio in ConfigLQT.

## 5 Commissioning

### 5.1 Programming of the transducer

"ConfigLQT" is a free configuration software, it is available for download from Tillquist homepage, [www.tillquist.com](http://www.tillquist.com). The software connects to the transducer and make it possible to change the configuration of adjustable parameters and to visualize live readings.

ConfigLQT supports offline configuration of adjustable parameters.

Save and load configuration file.

#### Functionality of ConfigLQT

ConfigLQT allows the user to:

- See online readings of measured values
- Adjust the functionality of the outputs
- Save parameter settings to a file
- Load parameter settings from a file
- Print settings report
- Upgrade firmware

### 5.2 LED functionality

LQT40A have two LEDs at front, *Power* and *Status*.

State	Power	Status
Start-up	Flashing - On 1 sec / Off 0.5 sec	Flashing - On 1 sec / Off 0.5 sec
Normal operation	On	Off
Modbus active	On	Flashing - On 200 ms / Off 200 ms
Error	Flashing - On 100 ms / Off 100 ms	Off

## 6 Technical Data

	<b>Technical Data</b>	<b>Details</b>
<b>Input</b>	Voltage range (Un)	100 – 400 V (L-L) main voltage (nominal)
	Measuring range	1 – 520 V TRMS L-L 50/60 Hz or 1 – 520 V TRMS L-L 16⅔ Hz
	Configurable measuring range	0 - 500 V L-L / 0 - 300 V L-N
	Frequency	50/60 Hz (10...40....70...120 Hz) 16⅔ Hz (10...15....18...120 Hz)
	Overload voltage	1.5 x Un – continuously, 2 x Un – 10 s
	Consumption	U x 1 mA / phase
	Current (In)	1 – 5 A
	Measuring range	5 mA – 10 A TRMS
	Configurable measuring range	0 – 10 A
	Overload current	2 x In continuously, 10 x In 15 s, 40 x In 1 s
<b>Output</b>	Consumption	<0.05 VA / phase
	Auxiliary power supply	24 – 230 VDC / 90 – 230 V AC ±10 %
	Burden	max 7.1 W / 15 VA
	Analog outputs	4 or 2
	Programmable range	±20mA, ±5 mA, ±10V (settings within the range)*
	Resolution	16 bits
	External resistance load	Current output: max 750 Ω (15 V) Voltage output: min 750 Ω
	Response time	<100 msec
	Ripple	≤0.2%
	Digital Outputs	2 (Energy pulse output) max 100 VAC/VDC 0.1 A
<b>General Data</b>	Communication	Modbus RS485 (RTU)
	Accuracy	0.2 (Ref. temp. 23 °C)
	Galvanic isolation	Supply, in- and output are galvanically isolated
	Connection terminals / Torque	Input and Auxiliary power supply: 6 mm² / 0.8 Nm Output: 2.5 mm² / 0.5 Nm
	Humidity	95 % non-condensing
	USB	USB Micro-B, port for configuration
	Temperature	-10...+55 °C (operation) -40...+70 °C (storage) Temperature coefficient < 0.1 % / 10 °C
	Test voltage	4 kV AC / 1 min
	Inputs	overvoltage cat. III
	Pollution degree	2
<b>Standards</b>	Dimension (W x H x D)	70 x 132 x 101 mm
	Weight	330 gr
	Protection	IP40 (housing), IP20 (terminals)
	IEC 60688:2021 Transducers	
	SS-EN 61010-1 Safety	
	EN 61000-6-2 / -6-4 / -6-5	

\*Depending on the version